

MODEL 250 PARTS LIST

ITEM	DESCRIPTION	PART NUMBER
1	BODY ASSEMBLY	08-250-00-630
2	FOOT	08-250-00-150
3	DRIVING BLADE	08-250-00-380
4	PLUNGER	07-250-00-370
5	PLUNGER SPRING	08-250-00-450
6	PLUNGER SPRING PIN	08-250-00-410
7	ROLLER PIN	08-250-00-640
8	1/4-20 x 1=3/4 S.H.C.S. (foot)	08-250-00-740
9	1/4-20 FLANGE NUT	08-250-00-750
10	ADAPTER FOOT	09-200-3005
11	CHANNEL	09-200-3008
12	GATE	09-200-3016
13	GATE PLATE	09-200-3017
14	SPOOL SET	09-200-3035
15	PUSHER SPRING	09-200-3034
16	#10-32 x 1/2 F.H. slotted	09-200-3057
17	SHIM	09-200-4000
18	C-1 PAD	09-200-4001
19	M-1 PAD	09-200-4002
20	B-1 PAD	09-200-4003
21	U-1 PAD	09-200-4004
22	#10-32 x 1-1/4 S.H.C.S. (knob)	09-445-29745
23	#10-32 x 1-1/4 S.H.C.S. (foot)	09-445-29754
24	#10-32 x 1-1/4 S.H.C.S. (gate)	09-445-29822
25	1/8 x 5/8 ROLL PINS	09-445-29741
26	NAIL PUSHER	09-445-29735
27	KNOB	09-445-297352
28	STANDOFF	09-445-29756
29	#8-32 x 1-1/2 F.H.C.S.	09-445-29750
30	#8-32 LOCKNUT	09-445-29751
31	BLADE RETAINER	08-45-00-580
32	COTTER PIN	08-45-00-610
ACCESSORY LIST		
	ALLEN WRENCH SET	AW-250
	CHANNEL ASSEMBLY	09-200-3061A
	NAIL PUSHER ASSEMBLY	09-445-29763A